



Technical Update

Important information about xSeries 255 Type 8685 server

This Technical Update provides additional information about IBM Director Version 3.1 that comes with your server.

If you plan to enable the Automatic Server Restart (ASR) feature and install the IBM Director application on your server, you must first install the ASR device driver that is available from the IBM Web site; then, install the IBM Director application and the appropriate Director System Support Package (DSSP) for your server.

To obtain the ASR device driver, go the IBM Web site at <http://www.ibm.com/> and click **Support & downloads**. Then, type *Advanced System Management 8685* in the Technical support database search field to locate the IBM Advanced System Management Device Driver Diskette for Microsoft Windows 2000 and Windows NT 4.0 Version 2.07 or later. Follow the directions in the README file for installation instructions.

When you install IBM Director 3.1, you must obtain the latest updates for IBM Director that are available on the Web. Go to the IBM Web site at <http://www.ibm.com/> and click **Support & downloads**. Then, type *Director 8685* in the Technical support database search field to locate the Director System Support Package for your server. Follow the directions in the README file for installation instructions.

IBM and xSeries are trademarks of the IBM Corporation in the United States, other countries, or both.

© Copyright International Business Machines Corporation 2002. All rights reserved.

Note to U.S. Government Users — Documentation related to restricted rights —use, duplication or disclosure is subject to restrictions set forth in GSA ADP Schedule Contract with IBM Corp.

Part Number: 48P9913

Printed in the U.S.A.



1P48P9913