

Table of contents

4-	1	DLXOFF -- Transmit XOFF character
5-	1	DLXON -- Transmit XON character
6-	1	DLINT -- DL terminal output interrupt entry point
6-	45	DLSTRT -- Start output to a DL11 line
7-	1	DZINT -- DZ terminal output interrupt entry point
8-	1	DZSTRT -- Start output to a DZ11 line
9-	1	NEDCHR -- Get next character for output
9-	14	REQCDQ -- Request clock-driven output processing
10-	1	SETSPD -- Set transmit/receive speed for a line
11-	1	GETDSS/SETDSS -- Get/set data set status

```

1          .TITLE  TSTIO  -- TSX-Plus terminal interrupt driver
2 000000   .PSECT  TSTIO
3          .ENABL  LC
4          .ENABL  AMA
5          ;
6          ; TSTIO contain the interrupt processing code for sending and receiving
7          ; characters to DL11, DZ11, and DH11 lines.
8          ;
9          .DSABL  GBL
10         ;
11         ; Global definitions
12         ;
13         .GLOBL  TSTIO, DLINT, DZOINT, CDSTRT, CDSTOP, NEDSOT
14         .GLOBL  CDIRTN, CDIFLG, CDORTN, CDOFLG, NEDCDI, NEDCDO
15         .GLOBL  ININT, CDSSPD, LINRTS, TTRSAV, TTINPT
16         .GLOBL  CDCLOK, CDQDSS, CDSOSS, CDSBRK, SETSPD
17         .GLOBL  CDSTR2, CDSXON, CDSXOF, DLSTRT, DZSTRT
18         .GLOBL  SILFET, TRNSTR, NEDCLO, TIOVEC, GETDSS, SETDSS
19         ;
20         ; Global references
21         ;
22         .GLOBL  $OITIM, $XCHAR
23         .GLOBL  KPAR6, LMXLN
24         .GLOBL  DHSSPD, VHSSPD, DHSBRK, VHSBRK
25         .GLOBL  LMXNUM
26         .GLOBL  LSW3, LSW5
27         .GLOBL  MXCSR, MXLNT
28         .GLOBL  MXTBUF, MXTCR, NEDCHR, PR7, PSW
29         .GLOBL  RLINE
30         .GLOBL  TBR, TRINT, TRRDY, TSR
31         .GLOBL  DHSTRT, DHSTOP, DLSBRK, DZSBRK, DZSSPD
32         .GLOBL  VHSTRT, DLCLOK, DLSSPD, $DHCDO
33         .GLOBL  DHXON, DHXOFF, VHXON, VHXOFF
34         .GLOBL  DZCLOK, DLQDSS, DZQDSS, DHQDSS, VHQDSS
35         .GLOBL  DLSOSS, DZSOSS, DHSOSS, VHSOSS
36         .GLOBL  LOUTIR, KPAR5
37         .GLOBL  LSW10
38         .GLOBL  $HISTP
39         .GLOBL  $SXOFF, LCDTYP
40         .GLOBL  $SXON
41         .GLOBL  VHSTOP, INTPRI
42         .GLOBL  DHCLOK, VHCLOK

```

```

1      ;-----
2      ; Macro definitions:
3      ;
4      ; Disable interrupts
5      ;
6      ;     .MACRO  DISABL          ;Disable interrupts
7      ;     BIS    #340, @PSW
8      ;     .ENDM  DISABL
9      ;
10     ; Enable interrupts
11     ;
12     ;     .MACRO  ENABL          ;Enable interrupts
13     ;     BIC    INTPRI, @PSW
14     ;     .ENDM  ENABL
15     ;
16     ; Call a routine in a system overlay
17     ;
18     ;     .MACRO  OCALL  ENTADD
19     ;     .IF    B, ENTADD
20     ;         .ERROR ;OCALL without entry address
21     ;     .ENDC
22     ;     CALL  OVRHC
23     ;     .WORD ENTADD
24     ;     .ENDM  OCALL
25     ;
26     ; The TTMAP and TTMAPX macros are used to map kernel-mode par6 to the
27     ; terminal character buffer area. The previous contents of par6 map
28     ; register are pushed on the stack and may be restored by using the
29     ; UNMAP or UNMAPX macros.
30     ; R1 must contain the line index number of the line whose buffers
31     ; are being accessed.
32     ; The difference between the TTMAP-UNMAP macros and the TTMAPX-UNMAPX
33     ; macros is that the X-versions are more efficient but may only be
34     ; used from within interrupt service routines where we are guaranteed
35     ; to be running on the system stack.
36     ; The TTMAP and UNMAP versions of the macros must only be
37     ; used in sections of code where the interrupts are disabled.
38     ;
39     ;     .MACRO  TTMAPX
40     ;     MOV    LTPAR(R1), @KPAR6
41     ;     .ENDM  TTMAPX
42     ;
43     ;
44     ;
45     ;     .MACRO  UNMAPX
46     ;     .ENDM  UNMAPX
47     ;
48     ;     .MACRO  TTMAP
49     ;     MOV    @KPAR6, MAPHLD
50     ;     MOV    LTPAR(R1), @KPAR6
51     ;     .ENDM  TTMAP
52     ;
53     ;     .MACRO  UNMAP
54     ;     MOV    MAPHLD, @KPAR6
55     ;     .ENDM  UNMAP

```

```

1
2 ; -----
3 ; Address vectors used to transfer control to device specific routines
4 ; based on the device type code (CDX$xxx).
5 ; Note: the entries in these vectors must be arranged in the same order
6 ; as the CDX$xxx values defined in TSGEN.
7 ;
8 ; Table of routines to call to initiate transmission to a line
9 ;
10 ; Inputs:
11 ; R1 = Physical line index number.
12 ;
13 TSTIO:
14 CDSTR1: .WORD DLSTRT ;DL11
15          .WORD DZSTRT ;DZ11
16          .WORD REQCD0 ;DH11
17          .WORD REQCD0 ;DHV11
18          .WORD DORTS ;Professional console
19          .WORD DORTS ;Professional communications port
20          .WORD DORTS ;Professional printer port
21          .WORD DORTS ;Professional quad serial line unit
22 ;
23 ; Table of routines used to perform actual hardware startup
24 ; of output transmission.
25 ;
26 CDSTR2: .WORD DORTS ;DL11
27          .WORD DORTS ;DZ11
28          .WORD DHSTRT ;DH11
29          .WORD VHSTRT ;DHV11
30          .WORD DORTS ;Professional console
31          .WORD DORTS ;Professional communications port
32          .WORD DORTS ;Professional printer port
33          .WORD DORTS ;Professional quad serial line unit
34 ;
35 ; Table of routines to call to stop transmission to a line.
36 ; (These routines are used if a ctrl-S is received)
37 ;
38 ; Inputs:
39 ; R1 = Physical line index number.
40 ;
41 CDSTOP: .WORD DORTS ;DL11
42          .WORD DORTS ;DZ11
43          .WORD DHSTOP ;DH11
44          .WORD VHSTOP ;DHV11
45          .WORD DORTS ;Professional console
46          .WORD DORTS ;Professional communications port
47          .WORD DORTS ;Professional printer port
48          .WORD DORTS ;Professional quad serial line unit
49 ;
50 ; Table of routines called to stuff an XOFF (ctrl-S) into the output
51 ; stream for a line.
52 ;
53 ; Inputs:
54 ; R1 = Line index number
55 ;
56 CDSXOF: .WORD DLXOFF ;DL11
57          .WORD DLXOFF ;DZ11
58          .WORD DHXOFF ;DH11

```

```

58 000066 0000000      .WORD  VHXOFF      ; DHV11
59 000070 000314'      .WORD  DLXOFF      ; Professional console
60 000072 000240'      .WORD  DORTS       ; Professional communications port
61 000074 000314'      .WORD  DLXOFF      ; Professional printer port
62 000076 000314'      .WORD  DLXOFF      ; Professional quad serial line unit
63
64      ;
65      ; Table of routine called to stuff an XON (ctrl-Q) into the output
66      ; stream for a line.
67      ;
68      ; Inputs:
69      ;   R1 = Line index number.
70      ;
71      ; CDSXON: .WORD  DLXON      ; DL11
72      ;         .WORD  DLXON      ; DZ11
73      ;         .WORD  DHXON      ; DH11
74      ;         .WORD  VHXON      ; DHV11
75      ;         .WORD  DLXON      ; Professional console
76      ;         .WORD  DORTS       ; Professional communications port
77      ;         .WORD  DLXON      ; Professional printer port
78      ;         .WORD  DLXON      ; Professional quad serial line unit
79      ;
80      ; Table of routines to be called on a 0.5 second basis to do line checking.
81      ;
82      ; Inputs:
83      ;   R1 = Physical line index number.
84      ;
85      ; CDCLOK: .WORD  DLCLOK     ; DL11
86      ;         .WORD  DZCLOK     ; DZ11
87      ;         .WORD  DHCLOK     ; DH11
88      ;         .WORD  VHCLOK     ; DHV11
89      ;         .WORD  DORTS       ; Professional console
90      ;         .WORD  DORTS       ; Professional communications port
91      ;         .WORD  DORTS       ; Professional printer port
92      ;         .WORD  DORTS       ; Professional quad serial line unit
93      ;
94      ; Table of routines to be called to get the data set status
95      ;
96      ; Inputs:
97      ;   R1 = Physical line index number.
98      ;
99      ; Outputs:
100     ;   R0 = Generic data set status flags (MS$xxx)
101     ;
102     ; CDGDSS: .WORD  DLGDSS     ; DL11
103     ;         .WORD  DZGDSS     ; DZ11
104     ;         .WORD  DHGDSS     ; DH11
105     ;         .WORD  VHGDSS     ; DHV11
106     ;         .WORD  DORTS       ; Professional console
107     ;         .WORD  DORTS       ; Professional communications port
108     ;         .WORD  DORTS       ; Professional printer port
109     ;         .WORD  DORTS       ; Professional quad serial line unit
110     ;
111     ; Table of routines to be called to set data set status
112     ;
113     ; Inputs:
114     ;   R0 = Data set control flags (MS$xxx)
115     ;   R1 = Physical line index number.

```

```

115
116 000160 000000G      ;
117 000162 000000G      CDSOSS: .WORD  DLSOSS      ;DL11
118 000164 000000G      .WORD  DZSOSS      ;DZ11
119 000166 000000G      .WORD  DHSOSS      ;DH11
120 000170 000240'      .WORD  VHSOSS      ;DHV11
121 000172 000240'      .WORD  DORTS      ;Professional console
122 000174 000240'      .WORD  DORTS      ;Professional communications port
123 000176 000240'      .WORD  DORTS      ;Professional printer port
124                      .WORD  DORTS      ;Professional quad serial line unit
125                      ;
126                      ; Table of routines to be called to control break transmission
127                      ;
128                      ; Inputs:
129                      ; RO = Break control flag (MS$BRK)
130                      ; RI = Physical line index number.
131                      ;
132 000200 000000G      CDSBRK: .WORD  DLSBRK      ;DL11
133 000202 000000G      .WORD  DZSBRK      ;DZ11
134 000204 000000G      .WORD  DHSBRK      ;DH11
135 000206 000000G      .WORD  VHSBRK      ;DHV11
136 000210 000240'      .WORD  DORTS      ;Professional console
137 000212 000240'      .WORD  DORTS      ;Professional communications port
138 000214 000240'      .WORD  DORTS      ;Professional printer port
139 000216 000240'      .WORD  DORTS      ;Professional quad serial line unit
140                      ;
141                      ; Table of routines to be called to control transmission speed
142                      ;
143                      ; Inputs:
144                      ; RO = Line speed code.
145                      ; RI = Line index number.
146                      ;
147 000220 000000G      CDSSPD: .WORD  DLSSPD      ;DL11
148 000222 000000G      .WORD  DZSSPD      ;DZ11
149 000224 000000G      .WORD  DHSPPD      ;DH11
150 000226 000000G      .WORD  VHSPPD      ;DHV11
151 000230 000240'      .WORD  DORTS      ;Professional console
152 000232 000240'      .WORD  DORTS      ;Professional communications port
153 000234 000240'      .WORD  DORTS      ;Professional printer port
154 000236 000240'      .WORD  DORTS      ;Professional quad serial line unit
155                      ;
156                      ; Dummy routine to do a simple return
157 000240 000207      DORTS:  RETURN
158                      ;
159                      ; -----
160                      ; Pointer vector to routines in TSTIQX module that is relocated over TSINIT.
161                      ;
162 000242      TIOVEC:
163 000242 000000      ININTP: .WORD  0
164 000244 000000      TTINPT: .WORD  0
165 000246 000000      SILFET: .WORD  0
166 000250 000000      TTRSAV: .WORD  0
167 000252 000000      TRNSTR: .WORD  0
168 000254 000000      NEDCP:  .WORD  0
169 000256 000000      CDORTN: .WORD  0
170 000260 000000      CDIRTN: .WORD  0
171 000262 000000      SNDFRE: .WORD  0

```

```

172 000264 177777          .WORD  -1          ;Signal end of vector
173
174
175          ; -----
176          ; Data areas
177 000266 000000  MAPHLD: .WORD  0          ;TEMP CELL USED BY TTMAP MACRO
178 000270 000000  NEDCDI: .WORD  0          ;Non-zero ==> Need clock driven input proc
179 000272 000000  NEDCDO: .WORD  0          ;Non-zero ==> Need clock driven output proc
180 000274 000000  NEDCLO: .WORD  0          ;Non-zero ==> Need CL output processing
181 000276 000000  NEDSOT: .WORD  0          ;Non-zero ==> Need output-low job scheduling
182
183          ; Byte data
184
185 000300      000  CDIFLQ: .BYTE  0          ;Non-zero ==> Input char fork routine running
186 000301      000  CDOFLQ: .BYTE  0          ;Non-zero ==> Output char fork routine running
187
188 000302      001  002  004  MXLBIT: .BYTE  1,2,4,10,20,40,100,200
      000305      010  020  040
      000310      100  200
189
190          .EVEN
191
192          ; Ignore an interrupt
193 000312 000207  LINRTS: RETURN          ;Ignore interrupt

```

DLXOFF -- Transmit XOFF character

```

1          .SBTTL  DLXOFF -- Transmit XOFF character
2          ;-----
3          ; DLXOFF is called to transmit an XOFF (ctrl-S) character to stop
4          ; transmission to us.
5          ;
6          ; Inputs:
7          ; R1 = Line index number.
8          ;
9 000314   DLXOFF:
10         ;
11         ; Set flag saying we have stopped the sender
12         ;
13 000314  052761  000000G 000000G      BIS    ##HISTP,LSW10(R1);Set flag saying we have stopped sender
14         ;
15         ; Set flag to cause an XOFF character to be sent by the transmitter
16         ; interrupt routine.
17         ;
18 000322  052761  000000G 000000G      BIS    ##SXOFF,LSW10(R1);Set flag saying to send XOFF
19         ;
20         ; Start the transmitter
21         ;
22 000330  016100  000000G      MOV     LCDTYP(R1),R0    ;Get device type code index
23 000334  004770  000000'      CALL   @CDSTRT(R0)     ;Call routine to start the transmitter
24         ;
25         ; Finished
26         ;
27 000340  000207      RETURN

```


DLXON -- Transmit XON character

```
1          .SBTTL  DLXON  -- Transmit XON character
2          ;-----
3          ; DLXON is called to transmit an XON (ctrl-Q) character.
4          ;
5          ; Inputs:
6          ;   R1 = Line index number.
7          ;
8 000342   DLXON:
9          ;
10         ; Clear flag that says XOFF has been sent
11         ;
12 000342   042761   000000G 000000G          BIC    ##HISTP,LSW10(R1);Clear flag that says XOFF has been sent
13         ;
14         ; Set flag to cause an XON character to be sent by the transmitter
15         ; interrupt routine.
16         ;
17 000350   052761   000000G 000000G          BIS    ##SXON,LSW10(R1);Force transmission of XON
18         ;
19         ; Start the transmitter
20         ;
21 000356   016100   000000G          MOV     LCDTYP(R1),R0    ;Get device type index number
22 000362   004770   000000'          CALL   @CDSTRT(R0)     ;Call routine to start the transmitter
23         ;
24         ; Finished
25         ;
26 000366   000207          RETURN
```

DLINT -- DL terminal output interrupt entry point

```

1          .SBTTL  DLINT  -- DL terminal output interrupt entry point
2          ;-----
3          ; DLINT contains the DL device specific output interrupt service routine.
4          ; The interrupt is vectored directly to an instruction sequence of the
5          ; form
6          ;
7          ;     JSR      R4,@#DLINT
8          ;     .WORD   line_number
9          ;
10         ; Thus on entry to DLINT R4 has been saved on the stack and currently
11         ; points to a word containing the line index number.
12         ;
13         ;
14 000370 010046 DLINT:  MOV      RO,-(SP)          ; Save registers (R4 already on stack)
15         ;
16         ; Obtain the interrupting physical line number.
17         ;
18 000372 011404         MOV      (R4),R4          ; Get physical line index number
19         ;
20         ; Get next character to transmit
21         ;
22 000374 004774 000000G CALL     @LOUTIR(R4)      ; Get next character for line
23 000400 103417         BCS     DLCLR          ; Br if no character available
24         ;
25         ; Transmit the character contained in RO.
26         ;
27 000402 052764 000000G 000000G BIS      #$XCHAR,LSW3(R4)  ; Set transmitter busy flag
28 000410 042764 000000G 000000G BIC      #$OITIM,LSW5(R4)  ; Start timer to catch lost interrupts
29 000416 032774 000000G 000000G 1$: BIT      #TRRDY,@TSR(R4)  ; Make sure transmitter is ready
30 000424 001774         BEQ     1$              ; Should never loop here
31 000426 110074 000000G         MOVB   RO,@TBR(R4)    ; Transmit the character
32         ;
33         ; Finished. Return from interrupt.
34         ;
35 000432 012600 DLRTN:  MOV      (SP)+,RO
36 000434 012604         MOV      (SP)+,R4          ; R4 was pushed by JSR instruction
37 000436 000002         RTI
38         ;
39         ; Disable transmit interrupts.
40         ;
41 000440 042764 000000G 000000G DLCLR:  BIC      #$XCHAR,LSW3(R4)  ; Set not busy transmit flag
42 000446 042774 000000G 000000G         BIC      #TRINT,@TSR(R4)  ; Disable transmit interrupt enable
43 000454 000766         BR      DLRTN              ; Return from interrupt
44         ;
45         .SBTTL  DLSTRT -- Start output to a DL11 line
46         ;-----
47         ; Start output to a DL11 line.
48         ; Enable transmit interrupts.
49         ; R1 = Physical line number
50         ;
51 000456 052771 000000G 000000G DLSTRT: BIS      #TRINT,@TSR(R1)  ; Enable transmit interrupt enable
52 000464 000207         RETURN
53

```

DZOINT -- DZ terminal output interrupt entry point

```

1          .SBTTL  DZOINT -- DZ terminal output interrupt entry point
2          ;-----
3          ; DZOINT contains the DZ device specific output interrupt service routine.
4          ; The interrupt is vectored directly to an instruction sequence of the
5          ; form
6          ;
7          ;     JSR      R5,@#DZOINT
8          ;     .WORD   mux_number
9          ;
10         ; Thus on entry to DZOINT R5 has been saved on the stack and currently
11         ; points to a word containing the mux index number.
12         ;
13         ;
14 000466 010046 DZOINT: MOV      RO,-(SP)          ; Save registers (R5 already on stack)
15 000470 010446      MOV      R4,-(SP)
16         ;
17         ; Obtain the interrupting physical line number.
18         ;
19 000472 011505      MOV      (R5),R5          ; Get mux index number
20 000474 017500 000000G  MOV      @MXCSR(R5),RO      ; Get the DZ CSR status register
21 000500 100022      BPL      DZRTN          ; Br if no line interrupted
22 000502 042700 000000C  BIC      #^C<RLINE>,RO     ; Isolate the interrupting line
23 000506 000300      SWAB     RO          ; Shift to right byte
24 000510 066500 000000G  ADD      MXLNT(R5),RO      ; Point to correct MUX line table
25 000514 111004      MOVB    (RO),R4          ; Get the physical line number
26 000516 001413      BEQ      DZRTN          ; Br if line not genned in system
27         ;
28         ; Obtain the next character for the interrupting line.
29         ;
30 000520 004774 000000G  CALL     @LOUTIR(R4)       ; Get the next character for line
31 000524 103414      BCS     DZCLR          ; Br if no character available
32         ;
33         ; Transmit the character contained in RO.
34         ;
35 000526 052764 000000G 000000G  BIS      #$XCHAR,LSW3(R4)   ; Set transmitter busy flag
36 000534 042764 000000G 000000G  BIC      #0ITIM,LSW5(R4)   ; Start timer to catch lost interrupts
37 000542 110075 000000G  MOVB    RO,@MXTBUF(R5)    ; Transmit the character
38         ;
39         ; Finished. Return from interrupt.
40         ;
41 000546 012604 DZRTN:  MOV      (SP)+,R4
42 000550 012600      MOV      (SP)+,RO
43 000552 012605      MOV      (SP)+,R5          ; R5 was saved by JSR
44 000554 000002      RTI
45         ;
46         ; Disable transmit interrupts.
47         ;
48 000556 042764 000000G 000000G DZCLR:  BIC      #$XCHAR,LSW3(R4)   ; Set not busy transmit flag
49 000564 016400 000000G  MOV      LMXLN(R4),RO     ; Get number of line within MUX
50 000570 146075 000302' 000000G  BICB    MXLBIT(RO),@MXTCR(R5) ; Disable transmitter interrupt
51 000576 000763      BR      DZRTN          ; Return from interrupt

```

DZSTRT -- Start output to a DZ11 line

```

1                                     .SBTTL  DZSTRT -- Start output to a DZ11 line
2                                     ;-----
3                                     ; Start output to a DZ11 line.
4                                     ; Enable transmit interrupts.
5                                     ; R1 = Physical line number
6                                     ;
7 000600 010046                      DZSTRT: MOV     R0, -(SP)           ; Save registers
8 000602 010546                      MOV     R5, -(SP)
9 000604 016105 000000G               MOV     LMXNUM(R1), R5         ; Get the MUX index number
10 000610 016100 000000G              MOV     LMXLN(R1), R0         ; Get number of line within MUX
11 000614 156075 000302' 000000G     BISB   MXLBIT(R0), @MXTCR(R5) ; Enable transmitter interrupt
12 000622 012605                      MOV     (SP)+, R5            ; Restore registers
13 000624 012600                      MOV     (SP)+, R0
14 000626 000207                      RETURN

```

NEDCHR -- Get next character for output

```

1          .SBTTL  NEDCHR -- Get next character for output
2          ;-----
3          ; This is a dummy resident routine which calls the relocated
4          ; NEDCHR routine in the TSTIOX module.
5          ;
6 000630 000177 177420 NEDCHR: JMP      @NEDCP          ;Call routine in TSTIOX
7          ;
8          ;-----
9          ; This is a dummy resident routine which calls the relocated
10         ; ININT routine in the TSTIOX module.
11         ;
12 000634 000177 177402 ININT:  JMP      @ININTP          ;Call routine in TSTIOX
13         ;
14         .SBTTL  REQCD0 -- Request clock-driven output processing
15         ;-----
16         ; REQCD0 is called to set a flag requesting clock-driven output
17         ; character processing.
18         ;
19         ; Inputs:
20         ; R1 = Physical line index number.
21         ;
22 000640 052761 0000000 0000000 REQCD0: BIS      #DHCDO,LSW10(R1)    ;Request clock-driven processing
23 000646 005237 000272'          INC      NEDCDO          ;Request output processing
24 000652 000207          RETURN          ;Finished

```

SETSPD -- Set transmit/receive speed for a line

```
1          .SBTTL  SETSPD -- Set transmit/receive speed for a line
2          ;-----
3          ; SETSPD is called to set the transmit/receive speed for a line.
4          ;
5          ; Inputs:
6          ;   R0 = Speed code.
7          ;   R1 = Line index number of line being set.
8          ;
9          SETSPD: MOV     R2, -(SP)
10         MOV     @#KPAR5, -(SP) ; Save kpar 5 in case an overlay is calling us
11         ;
12         ; Call hardware dependent routine to set the speed
13         ;
14         MOV     LCDTYP(R1), R2 ; Get hardware device type code
15         CALL    @CDSSPD(R2) ; Call routine to set the speed
16         ;
17         ; Finished
18         ;
19         MOV     (SP)+, @#KPAR5
20         MOV     (SP)+, R2
21         RETURN
```

GETDSS/SETDSS -- Get/set data set status

```

1          .SBTTL  GETDSS/SETDSS -- Get/set data set status
2          ;-----
3          ; Inputs: R1 contains line index
4          ;           For set, options are in R0 (for @CSDSS routine)
5          ; Outputs: For get, options are returned in R0 (by @CDGDSS routine)
6          ;
7 000702  005046  GETDSS: CLR      -(SP)          ; Say we are getting status
8 000704  000402          BR      DSSCOM        ; Br to common routine
9 000706  012746  000001 SETDSS: MOV      #1, -(SP)        ; Say we are setting data set status
10         ;
11 000712  010246  DSSCOM: MOV      R2, -(SP)
12 000714  013746  000000G MOV      @#KPAR5, -(SP) ; Save KPAR 5 in case overlay is calling us
13         ;
14         ; Call hardware dependent routine to get current data set status
15         ;
16 000720  016102  000000G MOV      LCDTYP(R1), R2 ; Get hardware device type code
17 000724  005766  000004  TST      4(SP)          ; Get or set data set status?
18 000730  001003          BNE      1$            ; Br if set
19 000732  004772  000140' CALL     @CDGDSS(R2)    ; Get data set status (into R0)
20 000736  000402          BR      2$            ; Br to exit
21 000740  004772  000160' 1$: CALL     @CSDSS(R2)    ; Set data set status (from R0)
22         ;
23         ; Clean up and return
24         ;
25 000744  012637  000000G 2$: MOV      (SP)+, @#KPAR5 ; Restore KPAR 5 mapping
26 000750  012602          MOV      (SP)+, R2
27 000752  005726          TST      (SP)+          ; Remove GET/SET flag from stack
28 000754  000207          RETURN
29         ;
30         .END

```

Errors detected: 0

*** Assembler statistics

```

Work file reads: 0
Work file writes: 0
Size of work file: 232 Words ( 1 Pages)
Size of core pool: 17920 Words ( 70 Pages)
Operating system: RT-11

```

```

Elapsed time: 00:00:08.52
DK: TSTID, LP: TSTID=DK: TSTID/C/N: SYM

```


ININTP	3-163#	9-12				
INTPRI	1-41					
KPAR5	1-36	10-10	10-19*	11-12	11-25*	
KPAR6	1-23					
LCDTYP	1-39	4-22	5-21	10-14	11-16	
LINRTS	1-15	3-193#				
LMXLN	1-23	7-49	8-10			
LMXNUM	1-25	8-9				
LQUTIR	1-36	6-22	7-30			
LSW10	1-37	4-13*	4-18*	5-12*	5-17*	9-22*
LSW3	1-26	6-27*	6-41*	7-35*	7-48*	
LSW5	1-26	6-28*	7-36*			
MAPHLD	3-177#					
MXCSR	1-27	7-20				
MXLBIT	3-188#	7-50	8-11			
MXLNT	1-27	7-24				
MXTBUF	1-28	7-37*				
MXTCR	1-28	7-50*	8-11*			
NEDCDI	1-14	3-178#				
NEDCDO	1-14	3-179#	9-23*			
NEDCHR	1-28	9-6#				
NEDCLO	1-18	3-180#				
NEDCP	3-168#	9-6				
NEDSOT	1-13	3-181#				
PR7	1-28					
PSW	1-28					
REQCDO	3-15	3-16	9-22#			
RLINE	1-29	7-22				
SETDSS	1-18	11-9#				
SETSPD	1-16	10-9#				
SILFET	1-18	3-165#				
SNDFRE	3-171#					
TBR	1-30	6-31*				
TIOVEC	1-18	3-162#				
TRINT	1-30	6-42	6-51			
TRNSTR	1-18	3-167#				
TRRDY	1-30	6-29				
TSR	1-30	6-29	6-42*	6-51*		
TSTIO	1-13	3-12#				
TTINPT	1-15	3-164#				
TTRSAV	1-15	3-166#				
VHCLOK	1-42	3-87				
VHQDSS	1-34	3-104				
VHSBRK	1-24	3-134				
VHSDSS	1-35	3-119				
VHSSPD	1-24	3-149				
VHSTOP	1-41	3-43				
VHSTRT	1-32	3-28				
VHXOFF	1-33	3-58				
VHXON	1-33	3-73				

DISABL	2-6#
ENABL	2-12#
OCALL	2-18#
TTMAP	2-48#
TTMAPX	2-39#
UNMAP	2-53#
UNMAPX	2-45#